

LOG SKIDDER ASSEMBLY INSTRUCTIONS



Shown with Optional 2" Ball Hitch Adapter Installed



Attach Tongue to the Skidder Frame:

- 2 each $\frac{1}{2}$ " x 3 $\frac{1}{2}$ " bolts
- 2 each $\frac{1}{2}$ " washers
- 2 each $\frac{7}{16}$ " washers
- 1 each backer plate
- 2 each $\frac{1}{2}$ " lock washers
- 2 each $\frac{1}{2}$ " nylock nuts

Install the $\frac{7}{16}$ " washers on the 3 $\frac{1}{2}$ " bolts, then install the backer plate as shown in the photo above. Push the bolts through the skid frame and attach the tongue using 2 each $\frac{1}{2}$ " washers. Then the $\frac{1}{2}$ " lockwashers, then the $\frac{1}{2}$ " nylock nuts. Tighten securely.



Slide the wheel onto the axle stub with the tire valve facing you. Install 1 each 1" washer and secure with a ¼" cotter pin as shown in the photo above. **Sealed bearings do not require greasing.**



Country Manufacturing, Inc.

P.O. Box 104

Fredericktown, OH 43019

PH: 740-694-9926

FAX: 740-694-5088

Toll Free: 1-800-335-1880