

AF-10 ADJUSTA-FLEX TINE HARROW Assembly Instructions

Step 1: Spread harrow out flat with tines downward until all chains are straight.

Step 2: From front of harrow (the end with the loose chains extending from it) insert the two long rods (one in each side) through the set of holes closest to the center of the harrow and attach with cotter pin on far end.

Step 3: Loop middle chain at front of harrow through the small circle on the draw ring and bolt back to chain.

Step 4: Loop side chains through large circle of draw ring, connecting back to the same chain using the quick link on the chain's end.

Note: Changes in aggression modes are achieved by lengthening or shortening the chains (step 3). The closer the quick link is located to the draw ring, the **more aggressive** the mode -- harrow will invert to a "v" shape. The farther away from the draw ring the quick link is located the **less aggressive** the mode -- as illustrated here at maximum width.

Country Manufacturing, Inc.
PO Box 104
333 Salem Ave Ext
Fredericktown, OH 43019
740 694 9926 - Phone
740 694 5088 - Fax

