

Gravity Latch Installation



With the stall door in the closed position, set your gravity latch at the desired height and mark a 3" x 3 3/4" cutout area. (make certain the gravity latch can be reached from inside of the stall).

Set the gravity latch so the stop is projecting out against the frame of the door, preventing the door from opening. Cut the opening as marked (approx. 3" x 3 3/4" with a recipricating saw.

Secure with 4 wood screws.

The gravity latch is installed correctly when the latch is lifted to allow the door to open and the latch falls automatically to secure the door from opening.